


# Operating Instructions

Single channel controller for level detection for NAMUR sensors

## VEGATOR 111



Document ID: 46105



# VEGA

# Contents

|           |  |           |
|-----------|--|-----------|
| <b>1</b>  | <b>About this document</b> .....                       | <b>4</b>  |
| 1.1       | Function .....   | 4         |
| 1.2       | Target group .....                                     | 4         |
| 1.3       | Symbols used.....                                      | 4         |
| <b>2</b>  | <b>For your safety</b> .....                           | <b>5</b>  |
| 2.1       | Authorised personnel .....                             | 5         |
| 2.2       | Appropriate use.....                                   | 5         |
| 2.3       | Warning about incorrect use.....                       | 5         |
| 2.4       | General safety instructions .....                      | 5         |
| 2.5       | Installation and operation in the USA and Canada ..... | 5         |
| 2.6       | Safety instructions for Ex areas .....                 | 6         |
| <b>3</b>  | <b>Product description</b> .....                       | <b>7</b>  |
| 3.1       | Configuration.....                                     | 7         |
| 3.2       | Principle of operation.....                            | 7         |
| 3.3       | Adjustment .....                                       | 8         |
| 3.4       | Packaging, transport and storage.....                  | 8         |
| <b>4</b>  | <b>Mounting</b> .....                                  | <b>9</b>  |
| 4.1       | General instructions .....                             | 9         |
| <b>5</b>  | <b>Connecting to power supply</b> .....                | <b>10</b> |
| 5.1       | Preparing the connection .....                         | 10        |
| 5.2       | Connection procedure.....                              | 11        |
| 5.3       | Wiring plan .....                                      | 11        |
| <b>6</b>  | <b>Setup</b> .....                                     | <b>13</b> |
| 6.1       | Adjustment system .....                                | 13        |
| 6.2       | Adjustment elements.....                               | 13        |
| 6.3       | Function table "Point level" .....                     | 16        |
| <b>7</b>  | <b>Diagnostics and servicing</b> .....                 | <b>17</b> |
| 7.1       | Maintenance .....                                      | 17        |
| 7.2       | Rectify faults.....                                    | 17        |
| 7.3       | Diagnosis, fault messages .....                        | 17        |
| 7.4       | How to proceed if a repair is necessary.....           | 18        |
| <b>8</b>  | <b>Dismount</b> .....                                  | <b>20</b> |
| 8.1       | Dismounting steps.....                                 | 20        |
| 8.2       | Disposal .....   | 20        |
| <b>9</b>  | <b>Certificates and approvals</b> .....                | <b>21</b> |
| 9.1       | Approvals for Ex areas .....                           | 21        |
| 9.2       | EU conformity.....                                     | 21        |
| 9.3       | SIL conformity (optional) .....                        | 21        |
| 9.4       | Environment management system .....                    | 21        |
| <b>10</b> | <b>Supplement</b> .....                                | <b>22</b> |
| 10.1      | Technical data .....                                   | 22        |
| 10.2      | Dimensions .....                                       | 24        |
| 10.3      | Industrial property rights.....                        | 25        |
| 10.4      | Trademark .....  | 25        |

**Supplementary documentation****Information:**

Supplementary documents appropriate to the ordered version come with the delivery. You can find them listed in chapter "*Product description*".

Editing status: 2021-07-12

# 1 About this document

## 1.1 Function

This instruction provides all the information you need for mounting, connection and setup as well as important instructions for maintenance, fault rectification, the exchange of parts and the safety of the user. Please read this information before putting the instrument into operation and keep this manual accessible in the immediate vicinity of the device.

## 1.2 Target group

This operating instructions manual is directed to trained personnel. The contents of this manual must be made available to the qualified personnel and implemented.

## 1.3 Symbols used



### Document ID

This symbol on the front page of this instruction refers to the Document ID. By entering the Document ID on [www.vega.com](http://www.vega.com) you will reach the document download.



**Information, note, tip:** This symbol indicates helpful additional information and tips for successful work.



**Note:** This symbol indicates notes to prevent failures, malfunctions, damage to devices or plants.



**Caution:** Non-observance of the information marked with this symbol may result in personal injury.



**Warning:** Non-observance of the information marked with this symbol may result in serious or fatal personal injury.



**Danger:** Non-observance of the information marked with this symbol results in serious or fatal personal injury.



### Ex applications

This symbol indicates special instructions for Ex applications.



### List

The dot set in front indicates a list with no implied sequence.



### Sequence of actions

Numbers set in front indicate successive steps in a procedure.



### Battery disposal

This symbol indicates special information about the disposal of batteries and accumulators.

## 2 For your safety

### 2.1 Authorised personnel

All operations described in this documentation must be carried out only by trained, qualified personnel authorised by the plant operator.

During work on and with the device, the required personal protective equipment must always be worn.

### 2.2 Appropriate use

VEGATOR 111 is a universal controller for connection of level switches.

You can find detailed information about the area of application in chapter " *Product description*".

Operational reliability is ensured only if the instrument is properly used according to the specifications in the operating instructions manual as well as possible supplementary instructions.

### 2.3 Warning about incorrect use

Inappropriate or incorrect use of this product can give rise to application-specific hazards, e.g. vessel overfill through incorrect mounting or adjustment. Damage to property and persons or environmental contamination can result. Also, the protective characteristics of the instrument can be impaired.

### 2.4 General safety instructions

This is a state-of-the-art instrument complying with all prevailing regulations and directives. The instrument must only be operated in a technically flawless and reliable condition. The operator is responsible for the trouble-free operation of the instrument. When measuring aggressive or corrosive media that can cause a dangerous situation if the instrument malfunctions, the operator has to implement suitable measures to make sure the instrument is functioning properly.

The safety instructions in this operating instructions manual, the national installation standards as well as the valid safety regulations and accident prevention rules must be observed by the user.

For safety and warranty reasons, any invasive work on the device beyond that described in the operating instructions manual may be carried out only by personnel authorised by the manufacturer. Arbitrary conversions or modifications are explicitly forbidden. For safety reasons, only the accessory specified by the manufacturer must be used.

To avoid any danger, the safety approval markings and safety tips on the device must also be observed.

### 2.5 Installation and operation in the USA and Canada

This information is only valid for USA and Canada. Hence the following text is only available in the English language.

Installations in the US shall comply with the relevant requirements of the National Electrical Code (ANSI/NFPA 70).

Installations in Canada shall comply with the relevant requirements of the Canadian Electrical Code.

## **2.6 Safety instructions for Ex areas**

For applications in explosion-proof areas (Ex), only devices with corresponding Ex approval may be used. Observe the Ex-specific safety instructions. These are an integral part of the operating instructions and are enclosed with every device with Ex approval.

## 3 Product description

### 3.1 Configuration

#### Scope of delivery

The scope of delivery encompasses:

- Controller VEGATOR 111
- Documentation
  - This operating instructions manual
  - Ex-specific "*Safety instructions*" (with Ex version)
  - Safety Manual "Functional safety (SIL) acc. to IEC 61508" (with SIL version)
  - If necessary, further certificates

#### Type label

The type label contains the most important data for identification and use of the instrument:

- Instrument type
- Information about approvals
- Technical data
- Serial number of the instrument
- QR code for device documentation
- Manufacturer information

#### Documents and software

Move to "[www.vega.com](http://www.vega.com)" and enter in the search field the serial number of your instrument.

There you can find the following information about the instrument:

- Order data
- Documentation
- Software

Alternatively, you can find all via your smartphone:

- Scan the QR-code on the type label of the device or
- Enter serial number manually in the VEGA Tools app (available free of charge in the respective stores)

### 3.2 Principle of operation

#### Application area

The VEGATOR 111 is a single-channel controller for level detection with level switches with NAMUR interface. Simple monitoring and control functions can be realised via the integrated relay. Typical applications are monitoring functions such as overfill and dry run protection. An optional fail safe relay is also available.

#### Functional principle

The VEGATOR 111 controller powers connected sensors and simultaneously processes their measuring signals.

When the medium reaches the switching point of the sensor, the sensor current changes. This is measured and evaluated by VEGATOR 111. The change causes the output relays to switch according to the set operating mode.

### 3.3 Adjustment

All adjustment elements are located under a hinged front cover. The operating mode and the line monitoring can be set via a DIL switch block. In addition, the correct function of the measuring system can be checked with a test key.

### 3.4 Packaging, transport and storage

#### Packaging

Your instrument was protected by packaging during transport. Its capacity to handle normal loads during transport is assured by a test based on ISO 4180.

The packaging of standard instruments consists of environment-friendly, recyclable cardboard. For special versions, PE foam or PE foil is also used. Dispose of the packaging material via specialised recycling companies.

#### Transport

Transport must be carried out in due consideration of the notes on the transport packaging. Nonobservance of these instructions can cause damage to the device.

#### Transport inspection

The delivery must be checked for completeness and possible transit damage immediately at receipt. Ascertained transit damage or concealed defects must be appropriately dealt with.

#### Storage

Up to the time of installation, the packages must be left closed and stored according to the orientation and storage markings on the outside.

Unless otherwise indicated, the packages must be stored only under the following conditions:

- Not in the open
- Dry and dust free
- Not exposed to corrosive media
- Protected against solar radiation
- Avoiding mechanical shock and vibration

#### Storage and transport temperature

- Storage and transport temperature see chapter " *Supplement - Technical data - Ambient conditions*"
- Relative humidity 20 ... 85 %



## 4 Mounting

### Mounting options

#### 4.1 General instructions

VEGATOR 111 is designed for carrier rail mounting (top hat rail 35 x 7.5 according to DIN EN 50022/60715). Due to its protection rating of IP20, the instrument is suitable for mounting in switching cabinets. It can be mounted horizontally and vertically.

**Note:**

When several instruments are mounted together without space in between, the ambient temperature at the installation location of the instrument must not exceed 60 °C. Around the ventilation slots there must be a distance of at least 2 cm to the next component.



VEGATOR 111 in Ex version is a corresponding, intrinsically safe instrument and must not be installed in hazardous areas. A safe operation is only ensured if the operating instructions and EU type approval certificate are observed. VEGATOR 111 must not be opened.

A distance of 50 mm to the intrinsically safe terminals must be ensured when mounting.

### Ambient conditions

The instrument is suitable for standard and extended ambient conditions acc. to DIN/EN/IEC/ANSI/ISA/UL/CSA 61010-1.

Make sure that the environmental and ambient conditions specified in chapter " *Technical data*" are maintained.

## 5 Connecting to power supply

### 5.1 Preparing the connection

#### Safety instructions

Always keep in mind the following safety instructions:



#### Warning:

Connect only in the complete absence of line voltage.

- Connect only in the complete absence of line voltage
- If overvoltage surges are expected, overvoltage arresters should be installed



#### Note:

Install a disconnecting device for the instrument which is easy to access. The disconnecting device must be marked for the instrument (IEC/EN 61010).

#### Safety instructions for Ex applications



In hazardous areas you must take note of the respective regulations, conformity and type approval certificates of the sensors and power supply units.

#### Voltage supply

The data for power supply are specified in chapter " *Technical data*".

#### Connection cable

The voltage supply of VEGATOR 111 is connected with standard cable according to the national installation standards.

The sensors are connected with standard two-wire cable without shielding. If electromagnetic interference is expected which is above the test values of EN 61326 for industrial areas, shielded cable should be used.

Make sure that the cable used has the required temperature resistance and fire safety for max. occurring ambient temperature

#### Cable screening and grounding

Connect the cable shielding on both ends to ground potential. In the sensor, the shielding must be connected directly to the internal ground terminal. The ground terminal on the outside of the sensor housing must be connected to the potential equalisation (low impedance).

If potential equalisation currents are expected, the connection on the processing side must be made via a ceramic capacitor (e. g. 1 nF, 1500 V). The low-frequency potential equalisation currents are thus suppressed, but the protective effect against high frequency interference signals remains.

#### Connection cable for Ex applications



Take note of the corresponding installation regulations for Ex applications. In particular, make sure that no potential equalisation currents flow over the cable screen. In case of grounding on both sides this can be achieved by the use of a capacitor or a separate potential equalisation.


### 5.2 Connection procedure

The pluggable terminals can be removed as needed to allow more convenient connection. To make the electrical connection, proceed as follows:

1. Mount the instrument as described in the previous chapter
2. Connect sensor cable to terminal 1/2, and where applicable, connect the shielding
3. Connect switched-off power supply to terminal 16/17
4. Connect relay to terminal 10/11/12
5. Option with fail safe relay: Connect relay to terminal 13/14/15

The electrical connection is finished.

### 5.3 Wiring plan



- 1 Sensor circuit (1.2/2.1 mA)
- 2 Relay output
- 3 Fail safe relay (optional)
- 4 Voltage supply



**Information:**

The connection terminals can be detached towards the front, if necessary. This can be useful when working in tight spaces or when exchanging an instrument.

## 6 Setup

### 6.1 Adjustment system




Fig. 1: Display and adjustment elements

- 1 Test key
- 2 DIL switch block
- 3 Signal lamps (LEDs)
- 4 Hinged front cover

### 6.2 Adjustment elements

#### Control lamps

Control lamps (LED) in the front plate indicate operation, switching status and fault signal.

- Green
  - Operating control lamp
  - Mains voltage on, instrument is operating
- Red
  - Fault indicator
  - Fault on the sensor circuit due to sensor failure or line break
  - The relay deenergises in case of failure

- Yellow
  - Relay control lamp
  - Lights with activated (current-carrying) relay status

### Front cover

The adjustment elements are located under a hinged front cover. To open it, use a small screwdriver in conjunction with the slot on the upper side of the front cover. To close it, push the cover at bottom and top firmly onto the front cover until you hear the two retaining clips snap in.

### DIL switch block

The DIL switch block is located behind the front cover. The individual switches are assigned as follows:




Fig. 2: DIL switch VEGATOR 111

- 1 Mode (min./max. adjustment)
- 2 Line monitoring Off/On

### Mode (min./max. adjustment)

The requested operating mode is set with the min./max. switch (min. detection i.e. dry run protection or max. detection i.e. overflow protection)

- **Dry run protection:** Relay is switched off when the level falls below the min. level (safe currentless state), relay is switched on again when the min. level is exceeded (switch-on point > switch-off point)
- **Overflow protection:** Relay is switched off when the max. level is exceeded (safe currentless state), relay is switched on again when the level falls below the max. level (switch-on point < switch-off point)



#### Note:

If the connected sensor has an own mode switch, then this switch must be set to "**Max.**".

### Line monitoring

When NAMUR level switches are connected, the line monitoring function can check the input continuously for line break or short-circuit. If a mechanical switch, e.g. a float switch, is to be connected, the line monitoring must be deactivated because only the switching conditions "open" or "closed" can be delivered.

### Test key

When level switches VEGAVIB/VEGAWAVE/VEGASWING in NAMUR version are connected, a function test can be carried out. The test key is recessed behind the front plate of the controller. Press the test key for at least one second with a suitable object (screwdriver, pen, etc.).



#### Note:

Keep in mind that downstream connected devices are activated during the function test. This allows you to check the correct function of the complete measuring system.

**Test procedure with VEGAVIB/VEGAWAVE**

Pushing the test key interrupts the circuit to the sensor and triggers a restart of the sensor. In the process, the conditions fault signal, full alarm (< 1 mA) and empty alarm (> 2.2 mA) are simulated one after the other. Check if a fault signal is triggered when you push the test key (red LED lights). The red LED does not light up when line monitoring is deactivated.

After the test key is released, the sensor is again supplied with voltage. During the warm-up phase of the sensor, the current briefly increases, which can energize the relay and the yellow LED. This is not relevant for the test assessment.

Once the sensor is ready for operation, a full alarm is simulated for approx. 3 s, the yellow LED does not light and the relay is deenergized. For a positive test assessment, the time must be between 2 s and 4 s. ①

Finally, an empty alarm is simulated by the sensor for approx. 1.5 s. The yellow LED lights and the relay is energized. For a positive test assessment, this time must be at least 1 s. ②

The test procedure is now finished, LED and relay return to the actual operating condition. ③




Fig. 3: Flow chart function test

- 1 Simulation full alarm
- 2 Simulation empty alarm
- 3 Current measurement status

**Test process with VEGASWING**

Pressing the test button interrupts the circuit to the sensor and thereby initiates a restart of the sensor. This only simulates a fault signal. Check whether the fault signal occurs when the test button is pressed (red LED lights up). If the line monitoring is deactivated, the red LED does not light up.

After releasing the test button, the sensor is supplied with voltage again. After that, if the function is correct, the red fault LED must no longer light up and the relays are energised or de-energised depending on the state of the sensor.



**Information:**

This test is accepted as proof test acc. to WHG.

### 6.3 Function table "Point level"

The following table provides an overview of the switching conditions depending on the set mode and the level.



#### Note:

The switching conditions in the tables are only valid if the mode switch on the sensor is set to "Max.".

#### Overfill protection, point level

| Sensor |                       | Controller          |                 |       |                            |
|--------|-----------------------|---------------------|-----------------|-------|----------------------------|
| Level  | Sensor current        | LED yellow (output) | LED red (fault) | Relay | Fail safe relay (optional) |
|        | > 2.1 mA              |                     |                 | ON    | ON                         |
|        | < 1.2 mA              |                     |                 | OFF   | ON                         |
| any    | < 0.35 mA<br>> 6.8 mA |                     |                 | OFF   | OFF                        |

#### Dry run protection, point level

| Sensor |                       | Controller          |                 |       |                            |
|--------|-----------------------|---------------------|-----------------|-------|----------------------------|
| Level  | Sensor current        | LED yellow (output) | LED red (fault) | Relay | Fail safe relay (optional) |
|        | < 1.2 mA              |                     |                 | ON    | ON                         |
|        | > 2.1 mA              |                     |                 | OFF   | ON                         |
| any    | < 0.35 mA<br>> 6.8 mA |                     |                 | OFF   | OFF                        |



## 7 Diagnostics and servicing

### 7.1 Maintenance

**Maintenance**

If the device is used properly, no special maintenance is required in normal operation.

**Cleaning**

The cleaning helps that the type label and markings on the instrument are visible.

Take note of the following:

- Use only cleaning agents which do not corrode the housings, type label and seals
- Use only cleaning methods corresponding to the housing protection rating

### 7.2 Rectify faults

**Reaction when malfunction occurs**

The operator of the system is responsible for taking suitable measures to rectify faults.

**Causes of malfunction**

The device offers maximum reliability. Nevertheless, faults can occur during operation. These may be caused by the following, e.g.:

- Measured value from sensor not correct
- Voltage supply
- Interference in the cables

**Fault rectification**

The first measure to be taken is to check the input and output signals. The procedure is described as follows. In many cases the causes can be determined this way and faults can be easily rectified.

**Reaction after fault rectification**

Depending on the reason for the fault and the measures taken, the steps described in chapter " *Setup*" must be carried out again or must be checked for plausibility and completeness.

**24 hour service hotline**

Should these measures not be successful, please call in urgent cases the VEGA service hotline under the phone no. **+49 1805 858550**.

The hotline is also available outside normal working hours, seven days a week around the clock.

Since we offer this service worldwide, the support is provided in English. The service itself is free of charge, the only costs involved are the normal call charges.

### 7.3 Diagnosis, fault messages

**Fault signal**

The controller and the connected sensors are permanently monitored during operation. If irregularities occur, a fault signal is triggered. In the event of a failure, the fault indication lights up and the relays are de-energized (safe state).

## Red fault LED lights up

| Cause                          | Rectification   |
|--------------------------------|---|
| Sensor not connected correctly | <ul style="list-style-type: none"> <li>● In Ex systems, make sure that the Ex protection is not influenced by the measuring instruments used.</li> <li>● Measure the current and voltage on the connection cable to the sensor</li> <li>● Faults in the sensor that cause a current change under 0.05 mA or over 6.8 mA lead to a fault signal with controllers.</li> <li>● In idle state, the terminal voltage (without sensor) is at least 8.2 V</li> <li>● The controller has an inner resistance of 1 kOhm. With this, the voltages for the different currents can be calculated.</li> </ul>  |
| Sensor current < 0.05 mA       | <ul style="list-style-type: none"> <li>● Check controller</li> <li>● Check the terminal voltage in idle state on the controller; if it is &lt; 8 V, the controller is defective -&gt; exchange controller or return it for repair</li> <li>● If the terminal voltage is &gt; 8 V, disconnect the sensor cable at the controller and replace it with a 1 kΩ resistor. If the fault signal does not disappear, the controller is defective -&gt; exchange controller or return it for repair</li> <li>● Check sensor or sensor cable</li> <li>● Reconnect the sensor cable to the controller, disconnect the sensor and replace it with a 1 kΩ resistor. If the fault signal does not disappear, then the sensor cable is broken -&gt; replace the sensor cable</li> <li>● If there is no longer a fault signal on the line, the sensor is defective -&gt; exchange sensor or return it for repair</li> </ul> |
| Sensor current > 6.8 mA        | <ul style="list-style-type: none"> <li>● Check controller</li> <li>● Disconnect sensor cable and replace it with a 1 kΩ resistor. If the fault signal does not disappear, the controller is defective -&gt; exchange controller or return it for repair</li> <li>● Check sensor or sensor cable</li> <li>● Reconnect the sensor cable to the controller, disconnect the sensor and replace it with a 1 kΩ resistor. If the fault signal does not disappear, then the sensor cable is short-circuited -&gt; eliminate the short-circuit or replace the sensor cable</li> <li>● If there is no longer a fault signal on the line, the sensor is defective -&gt; exchange sensor or return it for repair</li> </ul>  |

### 7.4 How to proceed if a repair is necessary

You can find an instrument return form as well as detailed information about the procedure in the download area of our homepage. By doing this you help us carry out the repair quickly and without having to call back for needed information.

In case of repair, proceed as follows:

- Print and fill out one form per instrument

- Clean the instrument and pack it damage-proof
- Attach the completed form and, if need be, also a safety data sheet outside on the packaging
- Ask the agency serving you to get the address for the return shipment. You can find the agency on our homepage.

## **8 Dismount**

### **8.1 Dismounting steps**

Take note of chapters "*Mounting*" and "*Connecting to voltage supply*" and carry out the listed steps in reverse order.

### **8.2 Disposal**

The device is made of recyclable materials. For this reason, it should be disposed of by a specialist recycling company. Observe the applicable national regulations.

## 9 Certificates and approvals

### 9.1 Approvals for Ex areas

Approved versions for use in hazardous areas are available or in preparation for the device series.

You can find the relevant documents on our homepage.

### 9.2 EU conformity

The device fulfils the legal requirements of the applicable EU directives. By affixing the CE marking, we confirm the conformity of the instrument with these directives.

The EU conformity declaration can be found on our homepage.

### 9.3 SIL conformity (optional)

Instruments with SIL option fulfill the requirements of functional safety according to IEC 61508. You can find further information in the supplied Safety Manual.

### 9.4 Environment management system

Protection of the environment is one of our most important duties. That is why we have introduced an environment management system with the goal of continuously improving company environmental protection. The environment management system is certified according to DIN EN ISO 14001. Please help us fulfil this obligation by observing the environmental instructions in chapters "*Packaging, transport and storage*", "*Disposal*" of these operating instructions.

## 10 Supplement

### 10.1 Technical data

#### Note for approved instruments

The technical data in the respective safety instructions are valid for approved instruments (e.g. with Ex approval). In some cases, these data can differ from the data listed herein.

All approval documents can be downloaded from our homepage.

#### General data

|                      |   |
|----------------------|---|
| Series               | Module unit for mounting on carrier rails 35 x 7.5 acc. to EN 50022/60715 |
| Weight               | 125 g (4.02 oz)   |
| Housing material     | Polycarbonate PC-FR   |
| Connection terminals |   |
| – Type of terminal   | Screw terminal  |
| – Wire cross-section | 0.25 mm <sup>2</sup> (AWG 23) ... 2.5 mm <sup>2</sup> (AWG 12)            |

#### Voltage supply

|                        |                                      |
|------------------------|--------------------------------------|
| Operating voltage      |                                      |
| – Nominal voltage AC   | 24 ... 230 V (-15 %, +10 %) 50/60 Hz |
| – Nominal voltage DC   | 24 ... 65 V (-15 %, +10 %)           |
| Max. power consumption | 2 W (8 VA)                           |

#### Sensor input

|                             |   |
|-----------------------------|---|
| Quantity                    | 1 x NAMUR                                   |
| Input type                  | Active (sensor power supply by VEGATOR 111) |
| Measured value transmission | Analogue 1.2/2.1 mA                         |
| Switching threshold         |   |
| – On                        | 1.5 mA                                      |
| – Off                       | 1.7 mA                                      |
| – Tolerance                 | ± 100 µA                                    |
| Current limitation          | Through internal resistance                 |
| Terminal voltage            | 8.2 V DC, ± 5 %                             |
| Internal resistance         | 1 kΩ, ± 1 %                                 |
| Detection line break        | ≤ 0.05 mA                                   |
| Detection shortcircuit      | ≥ 6.8 mA                                    |

#### Relay output

|                   |   |
|-------------------|---|
| Quantity          | 1 x operating relay, 1 x fail safe relay (optional) |
| Contact           | Floating spdt                                       |
| Contact material  | AgSnO <sub>2</sub> , hard gold-plated               |
| Switching voltage | min. 10 mV DC, max. 253 V AC/50 V DC                |
| Switching current | min. 10 µA DC, max. 3 A AC, 1 A DC                  |

|                                 |                                       |
|---------------------------------|---------------------------------------|
| Breaking capacity <sup>1)</sup> | min. 50 mW, max. 500 VA, max. 54 W DC |
| Phase angle $\cos \phi$ with AC | $\geq 0.7$                            |
| Switch-on/Switch-off delay      |                                       |
| – Basic delay                   | 100 ms                                |

---

### Indicators

---

|                             |                |
|-----------------------------|----------------|
| LED displays                |                |
| – Status, operating voltage | 1 x LED green  |
| – Status, fault signal      | 1 x LED red    |
| – Status, operating relay   | 1 x LED yellow |

---

### Adjustment

---

|                |                               |
|----------------|-------------------------------|
| 2 x DIL switch | Mode setting, line monitoring |
| Test key       | For line monitoring           |

---

### Ambient conditions

---

|  |                                  |
|--|----------------------------------|
| Ambient temperature at the installation site of the instrument | -20 ... +60 °C (-4 ... +140 °F)  |
| Storage and transport temperature                              | -40 ... +70 °C (-40 ... +158 °F) |
| Relative humidity  | < 96 %                           |

---

### Mechanical environmental conditions

---

|                            |  |
|----------------------------|--|
| Vibrations (oscillations)  | Class 4M4 acc. to IEC 60721-3-4 (1 g, 4 ... 200 Hz)                  |
| Impacts (mechanical shock) | Class 6M4 acc. to IEC 60721-3-6 (10 g/11 ms, 30 g/6 ms, 50 g/2.3 ms) |

---

### Electrical protective measures

---

|   |   |
|---|---|
| Protection rating                         | IP 20   |
| Overvoltage category (IEC 61010-1)        |   |
| – up to 2000 m (6562 ft) above sea level  | II  |
| – up to 5000 m (16404 ft) above sea level | II - Only with connected overvoltage protection |
| – up to 5000 m (16404 ft) above sea level | I   |
| Protection class                          | II  |
| Pollution degree                          | 2   |

---

### Measures for electrical separation

---

|   |        |
|---|--------|
| Reliable separation according to VDE 0106 part 1 between all circuits |        |
| – Reference voltage   | 253 V  |
| – Insulation resistance   | 5.1 kV |

<sup>1)</sup> If inductive loads or stronger currents are switched through, the gold plating on the relay contact surface will be permanently damaged. The contact is then no longer suitable for switching low-level signal circuits.

## Approvals

Instruments with approvals can have different technical specifications depending on the version.

For that reason the associated approval documents of these instruments have to be carefully noted. They are part of the delivery or can be downloaded by entering the serial number of your instrument into the search field under [www.vega.com](http://www.vega.com) as well as in the general download area.

## 10.2 Dimensions




Fig. 4: Dimensions VEGATOR 111



### 10.3 Industrial property rights

VEGA product lines are global protected by industrial property rights. Further information see [www.vega.com](http://www.vega.com).

VEGA Produktfamilien sind weltweit geschützt durch gewerbliche Schutzrechte.

Nähere Informationen unter [www.vega.com](http://www.vega.com).

Les lignes de produits VEGA sont globalement protégées par des droits de propriété intellectuelle. Pour plus d'informations, on pourra se référer au site [www.vega.com](http://www.vega.com).

VEGA lineas de productos están protegidas por los derechos en el campo de la propiedad industrial. Para mayor información revise la pagina web [www.vega.com](http://www.vega.com).

Линии продукции фирмы ВЕГА защищаются по всему миру правами на интеллектуальную собственность. Дальнейшую информацию смотрите на сайте [www.vega.com](http://www.vega.com).

VEGA系列产品在全球享有知识产权保护。

进一步信息请参见网站 < [www.vega.com](http://www.vega.com)。

### 10.4 Trademark

All the brands as well as trade and company names used are property of their lawful proprietor/originator.

**INDEX****C**

Cable screen 10  
Carrier rail 9  
Causes of malfunction 17  
Connection 11  
Connection cable 10  
Connection terminals 11  
Control lamps 13

**D**

DIL switch 13, 14  
Documentation 7  
Dry run protection 14

**E**

Ex version 9

**F**

Fault  
– Fault signal 17  
Fault rectification 17  
Fault signal 18

**G**

Grounding 10

**L**

LEDs 13  
Line monitoring 14

**M**

Mode 14

**N**

NAMUR 7

**O**

Overflow protection 14

**P**

Potential equalisation 10  
Protection rating 9

**Q**

QR code 7

**R**

Repair 18

**S**

Serial number 7  
Service hotline 17  
SIL 21

**T**

Test key 14  
Type label 7

**V**

Voltage supply 10



Printing date:

**VEGA**

All statements concerning scope of delivery, application, practical use and operating conditions of the sensors and processing systems correspond to the information available at the time of printing.

Subject to change without prior notice

© VEGA Grieshaber KG, Schiltach/Germany 2021



46105-EN-210714

VEGA Grieshaber KG  
Am Hohenstein 113  
77761 Schiltach  
Germany

Phone +49 7836 50-0  
E-mail: [info.de@vega.com](mailto:info.de@vega.com)  
[www.vega.com](http://www.vega.com)