Instruction Sheet


Thermo Scientific AquaSensors[™] RDO[®] Pro Sensor O-ring Replacement Kit, Cat. No. RDG1

Instructions

- 1. Use your fingers or a non-metallic tool to remove the worn O-rings from the grooves.
- 2. Clean all mating surfaces with a swab or lint-free cloth.
- 3. Using your fingers, apply a thin layer of lubricant evenly to the new O-rings.
- 4. Place the new O-rings in the grooves. Remove any excess lubricant.

Note: Take care to avoid transferring grease from you fingers to the gold pins on the sensor or the inner lens of the sensor. Clean the lens with the included wipe after placing the two O-rings on the sensor.





Process Water Instruments

North America 166 Cummings Center Beverly, MA 01915 USA Toll Free: 1-800-225-1480 Tel: 1-978-232-6000 Dom. Fax: 1-978-232-6015 Int'l Fax: 978-232-6031

Europe
P.O. Box 254, 3860 AG Nijkerk
Wallerstraat 125K, 3862 BN
Nijkerk, Netherlands
Tel: (31) 033-2463887
Fax: (31) 033-2460832

Collins, CO USA. All other trademarks are the property of Thermo Fisher Scientific Inc. and its subsidiaries.

Asia PacificBlk 55, Ayer Rajah Crescent
#04-16/24, Singapore 139949
Tel: 65-6778-6876
Fax: 65-6773-0836

www.thermo.com/processwater

