

Thermo Scientific™ AquaSensors™

RDO® Pro-X Sensor Cap Replacement Kit, Cat. No. RDC1X

Instructions

The sensor cap has a 2-year life after the instrument takes its first reading.

1. Pull the used sensor cap off of the sensor, without twisting it.
2. Remove the existing O-rings from the sensor.
3. Use a lint-free cloth to remove any moisture from the sensor body.
Note: Ensure that there is no moisture in the O-ring grooves. Avoid touching or cleaning the lens with anything other than the supplied lens wipe.
4. Use your finger to apply a layer of lubricant around the O-ring grooves. Place the O-rings on the sensor. Apply another thin layer of lubricant to the O-rings and grooves.
Note: Do not transfer grease to the lens or sensor pins.
5. Clean the lens on the sensor with the wipe provided in the kit and allow the lens to dry thoroughly. Inspect the lens for scratches or dirt.
6. Remove the new cap from its sealed packaging. Align the arrow on the cap with the index mark on the sensor and press the cap firmly, without twisting, until it seals over the sensor body. Make sure that the O-rings are not pinched or rolled between the cap and sensor.
7. Perform calibration.

Notes on the Sensor Cap

The cap's lifetime is 2 years after the first reading has been taken with the instrument.

Avoid allowing moisture, including atmospheric humidity, inside the cap. Keep the cap in its sealed packaging until you are ready to install it. Install the cap promptly after removing it from its package. Make sure that the O-ring grooves are dry and the O-ring is not rolled or pinched inside the cap.



thermoscientific.com/processwater

© 2014 Thermo Fisher Scientific Inc. All rights reserved. RDO is a registered trademark of In-Situ Inc., Fort Collins, CO USA. All other trademarks are the property of Thermo Fisher Scientific Inc. & its subsidiaries.

Water Analysis Instruments

North America
Toll Free: 1-800-225-1480
Tel: 1-978-232-6000
info.water@thermo.com

Netherlands
Tel: (31) 020-4936270
info.water.uk@thermo.com

China
Tel: (86) 21-68654588
wai.asia@thermofisher.com

India
Tel: (91) 22-4157-8800
wai.asia@thermofisher.com

Singapore
Tel: (65) 6778-6876
wai.asia@thermofisher.com

Japan
Tel: (81) 045-453-9175
wai.asia@thermofisher.com

Australia
Tel: (613) 9757-4300
in Australia (1300) 735-295
InfoWaterAU@thermofisher.com

Thermo
SCIENTIFIC

Part of Thermo Fisher Scientific